

GIGE FIRMWARE RELEASE NOTES

Manta CCD 1-Tap cameras

Manta G-031, -032, -033, -046, -125, -145, -146, -201, -504

2024-Jan-22 FW-Loader 40190



Scope of this document

These firmware release notes apply to all Manta CCD 1-tap cameras, except for cameras with frozen firmware or an NCA (no change agreement).



PvAPI

PvAPI: given only where naming varies in **PvAPI SampleViewer** versus **Vimba Viewer** and third-party software.



User sets

If new firmware contains a new feature or control, saved camera UserSets [PvAPI: ConfigFiles] will be invalidated and erased. Before loading new firmware, backup any used camera UserSets [PvAPI: see disk icon in SampleViewer to export current settings to file].



Firmware update instructions

For more information on updating the firmware on your Manta camera, see the Manta User Guide or the GigE Firmware Update application note at www.alliedvision.com/en/support/technical-papers-knowledge-base



Camera feature reference

A complete listing of camera features including definitions can be found online.

- Vimba and third-party software users: GigE Features Reference
- **PvAPI** users: GigE Camera and Driver Attributes document

www.alliedvision.com/en/support/technical-documentation



Supported models

Listed camera models include Manta CCD 1-Tap monochrome, color, NIR, and version variants (including hardware revisions). See the firmware loader executable for full list of variants.



Firmware releases in firmware loader 40190: Manta CCD 1-Tap

The following table lists a selection of firmware versions for your Manta camera.



Firmware loader for other Manta models

Firmware for Manta CCD 2-Tap and Manta CMOS models (Manta G-040, -158, -223, -235, -282, -283, -319, -419, -505, -507, -895, -917, -1236, -1620, -2040, -2460) is included in the GigE Firmware Loader. You can find the GigE Firmware Loader and related release notes at www.alliedvision.com/en/support/firmware-downloads.

Models	Firmware version	Release date
Manta G-031, G-033, G-046, G-145, G-145-30fps, G-146, G-201, G-504	FW 01.44.40190	2024-Jan-22

Table 1: Firmware releases at a glance (current firmware loader)

FW 01.44.40190

Release date: 2024-Jan-15



No firmware downgrade for cameras manufactured with new firmware

Cameras with <u>serial numbers >=503550795</u> are delivered with FW version 01.44.40190 or higher. To avoid damage, the firmware for these cameras cannot be reverted below 01.44.40190.

Cameras with <u>serial numbers <503550795</u> can be updated to any FW version.

Supported models

Camera family	Models	Firmware version
Manta	G-031, G-032, G-033, G-046, G-125, G-145, G-146, G-201, G-504	01.44.40190

Adjustments for new hardware

Adjustment to support the new Phy variant



Contact us

Website, email

General

www.alliedvision.com/en/contact info@alliedvision.com

Distribution partners

www.alliedvision.com/en/avt-locations/avt-distributors

Support

www.alliedvision.com/en/support www.alliedvision.com/en/about-us/contact-us/technical-support-repair-/-rma

Current firmware and release notes

https://www.alliedvision.com/en/support/firmware-downloads

Offices

Europe, Middle East, and Africa (Headquarters)

Allied Vision Technologies GmbH Taschenweg 2a 07646 Stadtroda, Germany T// +49 36428 677-0 (Reception) T// +49 36428 677-230 (Sales) F// +49 36428 677-28

Asia-Pacific

China

Allied Vision Technologies (Shanghai) Co., Ltd. 2-2109 Hongwell Int. Plaza 1602# ZhongShanXi Road Shanghai 200235, China T// +86 21 64861133

Singapore

Allied Vision Technologies Asia Pte. Ltd 82 Playfair Rd, #07-01 D'Lithium Singapore 368001 T// +65 6634 9027

North, Central, and South America

Canada

Allied Vision Technologies Canada Inc. 300 – 4621 Canada Way Burnaby, BC V5G 4X8, Canada T// +1 604 875 8855

USA

Allied Vision Technologies, Inc. 102 Pickering Way- Suite 502 Exton, PA 19341, USA Toll-free// +1-877-USA-1394 T// +1 978 225 2030

Copyright © 2024 Allied Vision Technologies GmbH. All rights reserved.