



## MIPI CSI-2 CAMERAS



# Direct Register Access Controls Reference

V2.5.1

Latest FW: 00.14.00.baba1e3c

# This reference at a glance

This document describes controls for the **Direct Register Access** of Alvium CSI-2 cameras.

CSI-2 access mode	Description
Direct Register Access 	Controls the camera by reading from and writing to registers, using an embedded board or an FPGA.
Video4Linux Access 	Controls the camera by V4L2 controls, using the Allied Vision MIPI CSI-2 V4L2 and GenICam Hybrid Driver directly.  Existing PC-based machine vision applications can be scaled down to V4L2 on lean embedded systems, reducing power consumption and costs.

*Table 1: CSI-2 Access modes overview*

Parameter	Value
Firmware release version	00.14.00. baba1e3c
CCI Register Layout Version	1.0

*Table 2: Supported firmware version and CCI Register Layout Version*

## What else do you need?

The following downloads provide additional information.

Document	Link
Alvium CSI-2 Cameras User Guide	<a href="http://www.alliedvision.com/en/support/technical-documentation/alvium-csi-2-documentation">www.alliedvision.com/en/support/technical-documentation/alvium-csi-2-documentation</a>
Various other documents and downloads	

*Table 3: Additional downloads overview*

# Contact us

## Website, email

### General

[www.alliedvision.com/en/contact](http://www.alliedvision.com/en/contact)

[info@alliedvision.com](mailto:info@alliedvision.com)

### Distribution partners

[www.alliedvision.com/en/avt-locations/avt-distributors](http://www.alliedvision.com/en/avt-locations/avt-distributors)

### Support

[www.alliedvision.com/en/support](http://www.alliedvision.com/en/support)

[www.alliedvision.com/en/about-us/contact-us/technical-support-repair/-/rma](http://www.alliedvision.com/en/about-us/contact-us/technical-support-repair/-/rma)

## Offices

### Europe, Middle East, and Africa (Headquarters)

Allied Vision Technologies GmbH  
Taschenweg 2a  
07646 Stadtroda, Germany  
T// +49 36428 677-0 (Reception)  
T// +49 36428 677-230 (Sales)  
F// +49 36428 677-28

### North, Central, and South America, Canada

Allied Vision Technologies Canada Inc.  
300 – 4621 Canada Way  
Burnaby, BC V5G 4X8, Canada  
T// +1 604 875 8855

### USA

Allied Vision Technologies, Inc.  
102 Pickering Way- Suite 502  
Exton, PA 19341, USA  
Toll-free// +1-877-USA-1394  
T// +1 978 225 2030

### Asia-Pacific

#### China

Allied Vision Technologies Shanghai Co Ltd.  
B-510, Venture International Business Park  
2679 Hechuan Road  
Minhang District, Shanghai 201103  
People's Republic of China  
T// +86 21 64861133

#### Japan

Allied Vision Technologies  
Yokohama Portside Bldg. 10F  
8-1 Sakae-cho, Kanagawa-ku  
Yokohama-shi, Kanagawa, 221-0052  
T// +81 (0) 45 577 9527

#### Singapore

Allied Vision Technologies Asia Pte. Ltd  
82 Playfair Rd, #07-01 D'Lithium  
Singapore 368001  
T// +65 6634 9027

# Contents

This reference at a glance .....	2
What else do you need? .....	2
Contact us .....	3
Document history and conventions .....	8
Document history .....	9
Conventions used in this document .....	12
Typographical styles .....	12
Symbols and notes .....	12
Controls access .....	13
Controls order .....	13
Reading register descriptions .....	13
0x0000   V4L2 Register Map Version .....	13
Explanation .....	13
Copyright and trademarks .....	14
Controls behavior and registers .....	15
Registers and address spaces .....	16
Pixel format naming .....	16
Improper operation .....	17
CCI registers .....	17
0x0000   CCI Register Layout Version .....	17
0x0008   Device Capabilities .....	18
0x0014   V4L2 Register Map Address .....	18
0x0018   Device GUID .....	18
0x0058   Manufacturer Name .....	19
0x0098   Model Name .....	19
0x00D8   Family Name .....	19
0x0118   Device Version .....	19
0x0158   Manufacturer Info .....	19
0x0198   Serial Number .....	20
0x01D8   User Defined Name .....	20
0x0218   Checksum .....	20
0x021E   Soft Reset .....	21
0x021F   Heartbeat .....	21
0x0220   Camera I2C Address .....	21
CSI-2 streaming setup .....	22
Numeric registers .....	23
Target values for auto controls .....	23
Controls processing order .....	24
Image data flow .....	24
Control interdependencies .....	25

V4L2 registers .....	26
Register offset .....	27
General controls .....	27
0x0000   V4L2 Register Map Version .....	27
0x0008   Register Inquiry .....	28
0x0010   Device Firmware Version .....	29
0x0018   Write Done Handshake .....	30
Streaming Control .....	31
0x0040   Supported CSI-2 Lane Counts .....	31
0x0044   CSI-2 Lane Count .....	31
0x0048   CSI-2 Clock Min Value .....	32
0x004C   CSI-2 Clock Max Value .....	32
0x0050   CSI-2 Clock .....	32
0x0054   Buffer Size .....	33
0x0078   CSI-2 Phy Reset .....	33
Acquisition Control .....	34
0x007C   Acquisition Start Delay .....	34
0x0080   Acquisition Start .....	34
0x0084   Acquisition Stop .....	35
0x008C   Acquisition Status .....	35
0x0090   Acquisition Frame Rate .....	36
0x0098   Acquisition Frame Rate Min Value .....	36
0x00A0   Acquisition Frame Rate Max Value .....	36
0x00B0   Acquisition Frame Rate Enable .....	37
0x00B4   Frame Start Trigger Mode .....	37
0x00B8   Frame Start Trigger Source .....	38
0x00BC   Frame Start Trigger Activation .....	38
0x00C0   Frame Start Trigger Software .....	39
0x00C8   Exposure Active Output Line Mode .....	39
0x00CC   Exposure Active Output Line .....	40
0x00D0   Line Configuration .....	41
0x00D4   Line Status .....	42
Image Format Control .....	43
0x0100   Width .....	43
0x0104   Width Min Value .....	43
0x0108   Width Max Value .....	43
0x010C   Width Increment .....	44
0x0110   Height .....	44
0x0114   Height Min Value .....	44
0x0118   Height Max Value .....	45
0x011C   Height Increment .....	45
0x0120   Offset X .....	45
0x0124   Offset X Min Value .....	46
0x0128   Offset X Max Value .....	46
0x012C   Offset X Increment .....	46

0x0130   Offset Y .....	47
0x0134   Offset Y Min Value .....	47
0x0138   Offset Y Max Value .....	47
0x013C   Offset Y Increment .....	48
0x0140   MIPI Data Format .....	48
0x0148   Available MIPI Data Formats .....	49
0x0150   Bayer Pattern Inquiry .....	50
0x0154   Bayer Pattern .....	50
0x0158   Reverse X .....	51
0x015C   Reverse Y .....	51
0x0160   Sensor Width .....	52
0x0164   Sensor Height .....	52
0x0168   Width Max .....	52
0x016C   Height Max .....	53
0x0170   Binning Inquiry .....	53
0x0174   Binning Setting .....	54
0x0178   Binning Mode .....	55
<b>Brightness Control .....</b>	<b>56</b>
0x0180   Exposure Time .....	56
0x0188   Exposure Time Min Value .....	56
0x0190   Exposure Time Max Value .....	56
0x0198   Exposure Time Increment .....	57
0x01A0   Exposure Auto .....	57
0x0330   Exposure Auto Min Value .....	58
0x0338   Exposure Auto Max Value .....	58
0x01A4   Intensity Auto Precedence .....	59
0x01A8   Intensity Auto Target Value .....	59
0x01AC   Intensity Auto Target Min Value .....	60
0x01B0   Intensity Auto Target Max Value .....	60
0x01B4   Intensity Auto Target Increment .....	60
0x01B8   Black Level .....	61
0x01BC   Black Level Min Value .....	61
0x01C0   Black Level Max Value .....	61
0x01C4   Black Level Increment .....	61
0x01C8   Gain .....	62
0x01D0   Gain Min Value .....	62
0x01D8   Gain Max Value .....	62
0x01E0   Gain Increment .....	63
0x01E8   Gain Auto .....	63
0x0340   Gain Auto Min Value .....	64
0x0348   Gain Auto Max Value .....	64
0x01F0   Gamma .....	65
0x01F8   Gamma Min Value .....	65
0x0200   Gamma Max Value .....	65
0x0208   Gamma Increment .....	66
<b>Color Management .....</b>	<b>67</b>
0x0240   Saturation .....	67

0x0244   Saturation Min Value .....	67
0x0248   Saturation Max Value .....	67
0x024C   Saturation Increment .....	68
0x0250   Hue .....	68
0x0254   Hue Min Value .....	68
0x0258   Hue Max Value .....	69
0x025C   Hue Increment .....	69
0x0280   Red Balance Ratio .....	69
0x0288   Red Balance Ratio Min Value .....	70
0x0290   Red Balance Ratio Max Value .....	70
0x0298   Red Balance Ratio Increment .....	70
0x02C0   Blue Balance Ratio .....	71
0x02C8   Blue Balance Ratio Min Value .....	71
0x02D0   Blue Balance Ratio Max Value .....	71
0x02D8   Blue Balance Ratio Increment .....	72
0x02E0   White Balance Auto .....	72
Other .....	73
0x0310   Device Temperature .....	73
Index .....	74

# Document history and conventions



This chapter includes:

Document history .....	9
Conventions used in this document .....	12
Copyright and trademarks .....	14



# Document history



## Alvium X- in document history entries

The letter X in Alvium X- represents any Alvium series, such as Alvium 1500 C or Alvium FP3.

Version	Date	Remarks
V2.5.1	2024-Nov-20	<p><b>Firmware versions</b></p> <ul style="list-style-type: none"> <li>Alvium CSI-2 main firmware: 00.14.00. baba1e3c</li> <li>Alvium X-050: 00.11.00.9cf0c21e</li> </ul> <p><b>Applied changes</b></p> <ul style="list-style-type: none"> <li>Updated values descriptions for <b>Gain Auto</b> in <a href="#">Brightness Control</a> on page 56.</li> <li>Applied editorial changes.</li> </ul>
V2.5.0	2024-Oct-11	<p><b>Firmware versions</b></p> <ul style="list-style-type: none"> <li><b>Release:</b> Alvium CSI-2 main firmware: 00.14.00. baba1e3c</li> <li>Alvium X-050: 00.11.00.9cf0c21e</li> </ul> <p><b>Applied changes</b></p> <ul style="list-style-type: none"> <li>Updated the title image to include Alvium FP3 and Alvium GM2 models.</li> <li>Updated addresses in <a href="#">Contact us</a> on page 3.</li> <li>Changes to <a href="#">CCI registers</a> on page 17.           <ul style="list-style-type: none"> <li>Updated the description for <b>Soft Reset</b>.</li> <li>Added <b>Heartbeat</b>.</li> </ul> </li> <li>Update diagrams for <a href="#">Image data flow</a> on page 24 and <a href="#">Control interdependencies</a> on page 25.</li> <li>Added links to <a href="#">Control interdependencies</a> on page 25 for the order of flipping and cropping of images.</li> <li>Added note in <a href="#">General controls</a> on page 27 to use <b>Write Done Handshake</b> only for V4L2 registers.</li> <li>In <a href="#">Image Format Control</a> on page 43:           <ul style="list-style-type: none"> <li>Removed “Digital” from Binning control names.</li> <li>Added options for sensor binning in <b>Binning Inquiry</b> and <b>Binning Setting</b>.</li> </ul> </li> <li>Updated firmware versions in this table.</li> <li>Applied editorial changes.</li> </ul>

Version	Date	Remarks
V2.4.2	2023-Sep-29	<p><b>Firmware versions</b></p> <ul style="list-style-type: none"> <li>• <b>Release:</b> Alvium CSI-2 main firmware: 00.12.00.00611a22</li> <li>• Alvium X-050: 00.11.00.9cf0c21e</li> </ul> <p><b>Applied changes</b></p> <ul style="list-style-type: none"> <li>• Corrected order for <i>YUV422 8-bit (UYVY)</i> option in <a href="#">0x0148   Available MIPI Data Formats</a> on page 49.</li> <li>• Added Write access for <a href="#">0x0154   Bayer Pattern</a> on page 50.</li> <li>• Applied editorial changes.</li> </ul>
V2.4.1	2023-Jun-15	<p><b>Firmware versions</b></p> <ul style="list-style-type: none"> <li>• <b>Release:</b> Alvium CSI-2 main firmware: 00.12.00.00611a22</li> <li>• Alvium X-050: 00.11.00.9cf0c21e</li> </ul> <p><b>Applied changes</b></p> <p>Corrected numbers in image data flow for <a href="#">Controls processing order</a> on page 24.</p>
V2.4.0	2023-Jun-05	<p><b>Firmware versions</b></p> <ul style="list-style-type: none"> <li>• <b>Release:</b> Alvium CSI-2 main firmware: 00.12.00.00611a22</li> <li>• Alvium X-050: 00.11.00.9cf0c21e</li> </ul> <p><b>Applied changes</b></p> <ul style="list-style-type: none"> <li>• Added register descriptions for Digital binning controls.</li> <li>• Added notes for <b>Height Max</b> and <b>Width Max</b> related to binning.</li> <li>• Added digital binning to <a href="#">Controls processing order</a> on page 24.</li> <li>• Changed unit MBps to Mbit/s for 0x0044 and 0x0048 registers.</li> <li>• Adjusted Line IDs in control descriptions to match the convention: Line2 uses GPIO-EXT2 and Line3 uses GPIO-EXT3.</li> <li>• Applied editorial changes.</li> </ul>

Version	Date	Remarks
V2.3.1	2021-Dec-17	<b>Firmware version:</b> 00.07.00.81db3896 <ul style="list-style-type: none"> <li>Removed information on Digital Binning because it is not supported by the current camera driver.</li> <li>Applied editorial changes.</li> </ul>
V2.3.0	2021-Dec-07	<b>Firmware version:</b> 00.07.00.81db3896 <ul style="list-style-type: none"> <li>Added <a href="#">Controls processing order</a> on page 24.</li> <li>Added register descriptions for <b>Camera I2C Address</b> controls in <a href="#">CCI registers</a> on page 17.</li> <li>Added register descriptions for <b>Digital Binning</b> controls in <a href="#">V4L2 registers</a> on page 26.</li> <li>Applied editorial changes.</li> </ul>
V2.2.0	2021-Apr-22	<b>Firmware version:</b> 00.04.00.34658 <ul style="list-style-type: none"> <li>Added RAW pixel formats for 10-bit and 12-bit Mono in               <ul style="list-style-type: none"> <li><b>MIPI Data Format</b></li> <li><b>Available MIPI Data Formats.</b></li> </ul> </li> <li>Correct the address for <b>YUV422 8-bit (UYVY)</b> in <b>MIPI Data Format</b></li> <li>Added register descriptions:               <ul style="list-style-type: none"> <li><b>Exposure Active Output</b> controls</li> <li><b>Line Configuration</b></li> <li><b>Line Status</b></li> </ul> </li> <li>Applied editorial changes.</li> </ul>
V2.1.0	2020-Dec-08	<b>Firmware version:</b> 00.03.00.31919 <ul style="list-style-type: none"> <li>Added register descriptions:               <ul style="list-style-type: none"> <li><b>Intensity Auto</b> controls</li> <li>Controls for value ranges of <b>Exposure Auto</b> <b>Gain Auto</b></li> <li>Controls for <b>Acquisition Frame Rate</b> <b>Frame Start Trigger</b></li> </ul> </li> <li>Changed pixel format naming to improve clarity. See <a href="#">Pixel format naming</a> on page 16.</li> <li>Applied editorial changes.</li> </ul>
V2.0.1	2020-Feb-14	<b>Firmware version:</b> 00.01.02.28100 <ul style="list-style-type: none"> <li>Added descriptions for target values used with <b>Exposure Auto</b> and <b>Gain Auto</b>.</li> <li>Reworked descriptions for register addresses.</li> </ul>

Version	Date	Remarks
V2.0.0	2020-Jan-06	<b>Firmware version:</b> 00.01.02.28100 <ul style="list-style-type: none"> <li>Added register descriptions to control <b>Width</b>, <b>Offset X</b>, <b>Saturation</b>, and <b>Hue</b>.</li> <li>Added notes for <b>Improper operation</b> on page 17.</li> <li>Applied editorial changes.</li> </ul>
V1.0.0	2019-Jun-14	<b>Firmware version:</b> 00.01.00.26405 Release version

## Conventions used in this document

To give this document an easily understood layout and to emphasize important information, the following typographical styles are used:

### Typographical styles

Style	Function
Control	Control names
<b>Emphasis</b>	Programs, or highlighting important things
<i>Value</i>	Control values (modes)
<a href="#">Web links and references</a>	Links to webpages and internal cross references

Table 4: Typographical styles

### Symbols and notes



#### Practical tip

Additional information helps to understand or ease handling the camera.



#### Avoiding malfunctions

Precautions are described.



#### Additional information

Web address or reference to an external source with more information is shown.

## Controls access

Acronym	Meaning
R/W	Read and write control
R/C	Read-only control that is constant
R	Read-only control that may change
W	Write-only control

Table 5: Controls access

## Controls order

The document defines controls listed by register address, grouped in categories.

## Reading register descriptions

The following example shows the description for **V4L2 Register Map Version**. Contents highlighted in **red** are explained below.

### 0x0000 | V4L2 Register Map Version

Displays the version of the V4L2 register map layout. The first version is **1.0**, where major version = **1**, minor version = **0**.

<b>Offset</b>	0x0000
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	16	Minor version of the V4L2 register map.
16	16	Major version of the V4L2 register map.

## Explanation

**Offset:** For CCI registers, addresses are absolute; for V4L2 registers, addresses are relative. Because of this, **Offset** is used for register addresses. See [Registers and address spaces](#) on page 16.

**LSB:** The LSB is shifted by the number of bits represented by **x**.

In the example, the LSB is shifted by 16 bit to set the value to *Major Version*.

## Copyright and trademarks

All text, pictures, and graphics are protected by copyright and other laws protecting intellectual property. All content is subject to change without notice.

All trademarks, logos, and brands cited in this document are property and/or copyright material of their respective owners. Use of these trademarks, logos, and brands does not imply endorsement.

Copyright © 2024 Allied Vision Technologies GmbH. All rights reserved.

# Controls behavior and registers




This chapter informs about writing registers:

Registers and address spaces .....	16
Pixel format naming .....	16
Improper operation .....	17
CCI registers .....	17
CSI-2 streaming setup .....	22
Numeric registers .....	23
Target values for auto controls .....	23
Controls processing order .....	24

## Registers and address spaces

Alvium CSI-2 cameras are operated via the Camera Control Interface (CCI) protocol, which requires a 16-bit address space. Within this space, different register maps can be found:

Register map	Function	Reference
CCI register map	Basic information	<a href="#">CCI registers</a> on page 17
V4L2 register map	<b>Video4Linux Access</b>	<a href="#">V4L2 registers</a> on page 26



The CCI address space used to operate Alvium CSI-2 cameras contains the CCI register map and the V4L2 register map. To get the absolute address of V4L2 registers, you must consider the offset of the CCI register map.

For the absolute address of V4L2 registers:

1. Read out [0x0014 | V4L2 Register Map Address](#) on page 18.
2. Add this value to the relative address of V4L2 registers in [V4L2 registers](#) on page 26.

## Pixel format naming

**In Direct Register Access**, Alvium CSI-2 cameras output pixel formats according to the MIPI CSI-2 standard, **in Video4Linux Access**, according to V4L2 definitions. This document states extended MIPI CSI-2 definitions:

Naming pattern	Examples
MIPI CSI-2 (FOURCC)	RAW8 (GREY)
	RGB888 (RGB3)

Table 6: Pixel format naming convention in specifications

Different names for equivalent formats:

MIPI CSI-2	V4L2	V4L2 FOURCC	PFNC <sup>1</sup>
YUV422 8-bit	V4L2_PIX_FMT_UYVY	UYVY	YCbCr422_8_CbYCrY
RGB888	V4L2_PIX_FMT_RGB24	RGB3	RGB8
RAW8	V4L2_PIX_FMT_GREY	GREY	Mono8

<sup>1</sup>GenICam Pixel Format Naming Convention

Table 7: Equivalent pixel formats in different standards



## Improper operation

If registers are not used properly, the camera may behave unexpectedly, such as changing values or ignoring operations. To avoid malfunctions and camera crashes, we recommend you to:

- Use only documented register addresses
- Keep values in the specified range
- Write only to registers specified for writing access, not to reading registers
- Write to one register at a time
- Ensure that the camera has completed writing to registers.  
Use [0x0018](#) | [Write Done Handshake](#) on page 30 to poll the camera.

As best practice, read written values back from the camera. Should errors occur:

- Verify register access options and adjust your script accordingly.
- Check for conflicts between settings.

## CCI registers

### 0x0000 | CCI Register Layout Version

Displays the version of the CCI register layout. This register is used to check for the compatibility of the register layout with the previous version. The first version is  $1.0$ , where major version =  $1$ , minor version =  $0$ .

<b>Offset</b>	0x0000
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4

<b>Bit offset (LSB &lt;&lt; x)</b>	<b>Width (bits)</b>	<b>Description</b>
0	16	Minor version of the CCI register layout.
16	16	Major version of the CCI register layout.

## 0x0008 | Device Capabilities

Displays information about the camera's capabilities, such as access modes or string encoding.

<b>Offset</b>	0x0008
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8

Bit offset (LSB << x)	Width (bits)	Description
0	1	User Defined Name is supported.
1	1	<b>Video4Linux Access</b> is supported.
2	2	<b>Vimba Access</b> is supported (selected models only).
4	4	String encoding of I2C string registers is supported. <ul style="list-style-type: none"> <li>0x0 -&gt; ASCII</li> </ul>
8	1	Family Name is supported.
9	55	Reserved.

## 0x0014 | V4L2 Register Map Address

Displays the address of V4L2 register map. Use as offset to get absolute addresses of V4L2 registers.

<b>Offset</b>	0x0014
<b>Type</b>	UInt16
<b>Access</b>	R
<b>Size [Bytes]</b>	2

## 0x0018 | Device GUID

Displays the GUID (Globally Unique Identifier) of the camera.

<b>Offset</b>	0x0018
<b>Type</b>	String
<b>Access</b>	R
<b>Size [Bytes]</b>	64

## 0x0058 | Manufacturer Name

Displays the camera manufacturer name.

<b>Offset</b>	0x0058
<b>Type</b>	String
<b>Access</b>	R
<b>Size [Bytes]</b>	64

## 0x0098 | Model Name

Displays the camera model name.

<b>Offset</b>	0x0098
<b>Type</b>	String
<b>Access</b>	R
<b>Size [Bytes]</b>	64

## 0x00D8 | Family Name

Displays the camera family name.

<b>Offset</b>	0x00D8
<b>Type</b>	String
<b>Access</b>	R
<b>Size [Bytes]</b>	64

## 0x0118 | Device Version

Displays the camera's device version.

<b>Offset</b>	0x0118
<b>Type</b>	String
<b>Access</b>	R
<b>Size [Bytes]</b>	64

## 0x0158 | Manufacturer Info

Displays the manufacturer information.

<b>Offset</b>	0x0158
<b>Type</b>	String
<b>Access</b>	R
<b>Size [Bytes]</b>	64

## 0x0198 | Serial Number

Displays the camera's serial number.

<b>Offset</b>	0x0198
<b>Type</b>	String
<b>Access</b>	R
<b>Size [Bytes]</b>	64

## 0x01D8 | User Defined Name

Controls the user defined name.

<b>Offset</b>	0x01D8
<b>Type</b>	String
<b>Access</b>	R/W
<b>Size [Bytes]</b>	64

## 0x0218 | Checksum

Displays the checksum which can be used for the register space 0x0000 to 0x0217.

<b>Offset</b>	0x0218
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4

Use this control to check if data was transferred to the host correctly. Make sure that the host calculates the checksum with the following parameters:

<b>Name</b>	JAMCRC
<b>Width</b>	32 bit
<b>Polynomial</b>	0x4C11DB7
<b>Input reflected</b>	Yes
<b>Output reflected</b>	Yes
<b>Output XOR value</b>	0x00000000
<b>Example output for ASCII input string "123456789" (9 bytes)</b>	0x340BC6D9

## 0x021E | Soft Reset

Performs a soft reset of the camera.

<b>Offset</b>	0x021E
<b>Type</b>	UInt8
<b>Access</b>	W
<b>Size [Bytes]</b>	1

To reset the camera:

1. Write 0x80 to **Heartbeat**.
2. Write **1** to **Soft Reset**.  
This initiates the reset.
3. Poll **Heartbeat** every 400 milliseconds.  
The camera has been successfully reset, when the register value is >0 and <0x80.

**Note:** The camera's boot / reset time is about 5 to 8 seconds.

## 0x021F | Heartbeat

Controls the current heartbeat (clock frequency) of the CSI-2 link.

**Note:** The register value is incremented by **1** every 500 milliseconds approximately. When **255** is reached, it falls back to **0**.

<b>Offset</b>	0x021F
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1

## 0x0220 | Camera I2C Address

Controls the I2C address that becomes valid after the next camera reboot.

<b>Offset</b>	0x0220
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1

<b>Value</b>	<b>Description</b>
0x3C	Default value

## CSI-2 streaming setup

The following steps must be performed to transfer a lane count and clock frequency for CSI-2 between host and device:

1. The host determines which lane counts are supported by the host (by such as hardware and driver).
2. The host reads the **Supported CSI-2 Lane Count** register from the device. This register contains a bitfield to indicate which lane counts are supported by the device.
3. The host selects a lane count that is compatible to host and device. Potential modes:
  - Automatically select the highest lane count supported by host and device.
  - Manually select one of the lane counts that are supported by host and device.
4. The host determines the CSI clock frequency range supported by host (by hardware, driver etc.) for the selected lane count (from step 3).
5. The host writes the selected lane count (from step 3) into the **CSI-2 Lane Count** register.
6. The host reads **CSI-2 Clock Min Value** and **CSI-2 Clock Max Value** registers to get the range for the clock frequency supported by the device for the selected lane count (from step 3).
7. The host selects a clock frequency that is compatible to host and device. Potential modes:
  - Automatically select the highest clock frequency supported by host and device.
  - Manually select a clock frequency that is supported by host and device.
8. The host writes selected clock frequency (from step 7) to the **CSI-2 Clock** register. The device may not be able to support the exact clock frequency selected. In this case it will use the highest clock frequency that is lower or equal to the clock frequency written to the register.

**Example:** The transport layer writes 650 MHz to the register of a device that only supports clock frequencies with a multiple of 100 MHz. In this case the device uses a clock frequency of 600 MHz ( $6 \times 100$  MHz).

9. The host reads the actual clock frequency from the **CSI-2 Clock** register.
10. The host checks if the actual clock frequency used in the device (from step 9) lies in the range of clock frequencies supported by the host (from step 4). If not, image acquisition cannot be started, and an error will be issued on the host.

Sometimes, this procedure does not transfer a lane count or it does not select a compatible clock frequency supported by the host. In this case, image acquisition cannot be started and an error is issued on the host.

The host must perform this negotiation during opening the device (for example, so that any frame rate limit calculation in the device can take the result of this negotiation into consideration).

## Numeric registers

Most of the numeric controls listed in the next chapter consist of a list of four registers:

1. Value register: Used for reading or writing the current value of the control.
2. Minimum register: The minimal value that can be set to the value register.
3. Maximum register: The maximal value that can be set to the value register.
4. Increment register: The step or increment of values valid for the value register (beginning with minimal value).

For such a control, a valid value must hold the following three conditions true:

1. Value  $\geq$  minimum
2. Value  $\leq$  maximum
3.  $((\text{Value} - \text{minimum}) \% \text{increment}) == 0$

If a value is written to such value register that is not valid, the camera will correct the value to the nearest valid value. The updated or corrected value can be read back by the user.

This control behavior is used for the following controls:

- Acquisition Frame Rate
- Black Level
- Blue Balance Ratio
- Exposure Time
- Gain
- Gamma
- Height
- Hue
- Intensity Auto Target
- Offset X
- Offset Y
- Red Balance Ratio
- Saturation
- Width

## Target values for auto controls

**Exposure Auto** and **Gain Auto** adjust the mean pixel intensity to a target value of 50% between minimum and maximum. Use **Intensity Auto Target** controls to adjust the target value (with a tolerance of 5%). Use **Intensity Auto Precedence** to set the priority between **Exposure Auto** and **Gain Auto**.

# Controls processing order

## Image data flow

To develop your application effectively, note the order in which the controls are **processed** in Alvim cameras. In the Alvim user guides, the image data flow describes the sequence of image processing steps inside the camera. The shown functionalities represent controls or control groups.

See [Control interdependencies](#) on page 25 for the recommended order to **configure** the camera.





Figure 1: Image data flow for Alvim CSI-2 cameras



## Control interdependencies

The conversion between time and clock cycles affects control values. Features for pixel format, bandwidth, cropping (ROI), exposure time, and triggering are related to each other. Changing values for one control can change values for another control. For example, frame rates can be reduced when **Mipi Data Format** is changed subsequently. [Figure 2](#) shows the interdependencies.



*Figure 2: Interdependencies between controls*

# V4L2 registers



This chapter defines controls listed by register address and grouped in controls categories:

Register offset .....	27
General controls.....	27
Streaming Control .....	31
Acquisition Control.....	34
Image Format Control.....	43
Brightness Control.....	56
Color Management .....	67
Other .....	73

## Register offset

The CCI address space used to operate Alvium CSI-2 cameras contains the CCI register map and the V4L2 register map. To get the absolute address of V4L2 registers, you must consider the offset of the CCI register map.

For the absolute address of V4L2 registers:

1. Read out [0x0014 | V4L2 Register Map Address](#) on page 18.
2. Add this value to the relative address of V4L2 registers.

## General controls

### 0x0000 | V4L2 Register Map Version

Displays the version of the V4L2 register map layout. The first version is **1.0**, where major version = **1**, minor version = **0**.

<b>Offset</b>	0x0000
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All camera models

<b>Bit offset (LSB &lt;&lt; x)</b>	<b>Width (bits)</b>	<b>Description</b>
0	16	Minor version of the V4L2 register map.
16	16	Major version of the V4L2 register map.

## 0x0008 | Register Inquiry

Displays if non-mandatory registers are available.

**Note:** Availability can change during runtime.

<b>Offset</b>	0x0008
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	1	Reverse X is available.
1	1	Reverse Y is available.
2	1	Intensity Auto controls are available.
3	1	Black Level controls are available.
4	1	Gain controls are available.
5	1	Gamma controls are available.
6	1	Reserved
7	1	Saturation controls are available.
8	1	Hue controls are available.
9	1	White Balance is available.
10	1	Reserved
11	1	Exposure Auto controls are available.
12	1	Gain Auto controls are available.
13	1	White Balance Auto is available.
14	1	Device Temperature is available.
15	1	Reserved
16	1	Acquisition Frame Rate controls are available.
17	1	Frame Start Trigger controls are available.
18	1	Exposure Active Output Line is available.
19 to 63	45	Reserved <b>Set to 0.</b>

## 0x0010 | Device Firmware Version

Displays the current firmware version installed on the camera.

<b>Offset</b>	0x0010
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All camera models

<b>Bit offset (LSB &lt;&lt; x)</b>	<b>Width (bits)</b>	<b>Description</b>
0	8	Special firmware version.
8	8	Major firmware version.
16	16	Minor firmware version.
32	32	Patch firmware version.

## 0x0018 | Write Done Handshake

**Read access:** The camera confirms that the previous write access to registers has been processed.

**Write access:** Enables the control and resets the success confirmation.

**Note:** Handshake must only be used for V4L2 registers, not for CCI registers.

<b>Offset</b>	0x0018
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Bit offset (LSB &lt;&lt; x)</b>	<b>Width (bits)</b>	<b>Description</b>
0	1	<b>1:</b> The camera confirms the previous write access has been processed. <b>0:</b> Written by the host to reset this flag.
1	6	Reserved, set to <b>0</b> .
7	1	<b>1:</b> The camera outputs if it supports Write Done Handshake.

# Streaming Control

## 0x0040 | Supported CSI-2 Lane Counts

Displays the CSI-2 lane counts supported by the camera.

<b>Offset</b>	0x0040
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	1	1-lane operation is supported.
1	1	2-lane operation is supported.
2	1	3-lane operation is supported.
3	1	4-lane operation is supported.
4	4	Reserved <b>Set to 0.</b>

## 0x0044 | CSI-2 Lane Count

Controls the current CSI-2 lane count.

**Note:** This control must be set before [0x0050 | CSI-2 Clock](#). See [CSI-2 streaming setup](#) on page 22 for details.

[0x0048 | CSI-2 Clock Min Value](#) supports a minimum value of 80 Mbit/s per lane. Select suitable settings so that the resulting data rate is supported by the host.

<b>Offset</b>	0x0044
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

## 0x0048 | CSI-2 Clock Min Value

Displays the minimum CSI-2 clock frequency supported for the current CSI-2 lane count.

**Note:** The minimum supported value per lane is 80 Mbit/s. Select suitable settings for this control and for [0x0044 | CSI-2 Lane Count](#), so that the resulting data rate is supported by the host.

<b>Offset</b>	0x0048
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Hertz
<b>Availability</b>	All camera models

## 0x004C | CSI-2 Clock Max Value

Displays the maximum CSI-2 clock frequency supported for the current CSI-2 lane count.

<b>Offset</b>	0x004C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Hertz
<b>Availability</b>	All camera models

## 0x0050 | CSI-2 Clock

Controls the current CSI-2 clock frequency.

**Note:** Set [0x0044 | CSI-2 Lane Count](#) before this control. See [CSI-2 streaming setup](#) on page 22 for details.

<b>Offset</b>	0x0050
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	Hertz
<b>Availability</b>	All camera models



## 0x0054 | Buffer Size

Displays the size of the streaming buffer (payload).

<b>Offset</b>	0x0054
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Bytes
<b>Availability</b>	All camera models

## 0x0078 | CSI-2 Phy Reset

Controls the Phy (physical layer) reset state.

<b>Offset</b>	0x0078
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
0	CSI-2 Phy is operated normally.
1	CSI-2 Phy is held in reset state.

# Acquisition Control

## 0x007C | Acquisition Start Delay

Controls the timeout until **Acquisition Start** is executed.

<b>Offset</b>	0x007C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	Milliseconds
<b>Availability</b>	All camera models

## 0x0080 | Acquisition Start

Starts the acquisition. Reading the register returns the command value until the acquisition is stopped or aborted. Otherwise  $0$  is returned.

**Read access:** The register returns  $1$  if acquisition is active and  $0$  if acquisition has been stopped.

**Note:** The D-Phy only resets if **Acquisition Start Delay** is greater than  $0$ .

<b>Offset</b>	0x0080
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
$1$	Starts the acquisition.

## 0x0084 | Acquisition Stop

Stops the acquisition **after the current frame has been acquired**.

**Read access:** The register returns **1** if acquisition is active and **0** if acquisition has been stopped.

<b>Offset</b>	0x0084
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
<b>1</b>	Stops the acquisition.

## 0x008C | Acquisition Status

Displays if the camera is acquiring images.

<b>Offset</b>	0x008C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
<b>0</b>	Acquisition has been stopped.
<b>1</b>	Acquisition has been started or is running.

## 0x0090 | Acquisition Frame Rate

Controls the frequency at which the frames are captured.

<b>Offset</b>	0x0090
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Unit</b>	Micro Hertz [ $\mu$ Hz]
<b>Availability</b>	All camera models

## 0x0098 | Acquisition Frame Rate Min Value

Displays the minimum value for Acquisition Frame Rate.

<b>Offset</b>	0x0098
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Micro Hertz [ $\mu$ Hz]
<b>Availability</b>	All camera models

## 0x00A0 | Acquisition Frame Rate Max Value

Displays the maximum value for Acquisition Frame Rate.

<b>Offset</b>	0x00A0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Micro Hertz [ $\mu$ Hz]
<b>Availability</b>	All camera models

## 0x00B0 | Acquisition Frame Rate Enable

Enables or disables Acquisition Frame Rate.

**Note:** Acquisition Frame Rate is used only if Frame Start Trigger Mode is set to *Off*.

<b>Offset</b>	0x00B0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
0	Acquisition Frame Rate is disabled.
1	Acquisition Frame Rate is enabled.

## 0x00B4 | Frame Start Trigger Mode

Enables or disables the Frame Start Trigger.

<b>Offset</b>	0x00B4
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
0	The Frame Start Trigger is disabled.
1	The Frame Start Trigger is enabled.

## 0x00B8 | Frame Start Trigger Source

Selects the internal signal or physical input line to use as trigger source.

### Notes:

- To use this control, the **Frame Start Trigger Mode** must be set to *On*.
- Line 2 and line 3 are used for I2C.

<b>Offset</b>	0x00B8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
0	Line2 is selected.
1	Line3 is selected.
4	Software is selected.

## 0x00BC | Frame Start Trigger Activation

Selects how signals activate the **Frame Start Trigger**.

<b>Offset</b>	0x00BC
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
0	The trigger is enabled on the rising edge of the signal.
1	The trigger is enabled on the falling edge of the signal.
2	The trigger is enabled on the any edge of the signal.
3	The trigger is enabled by a high-level signal.
4	The trigger is enabled by a low-level signal.

## 0x00C0 | Frame Start Trigger Software

Generates a software trigger.

**Note:** Trigger Source must be set to *Software*.

<b>Offset</b>	0x00C0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

Value	Description
1	A trigger is generated.



### Recommended workflow for using the exposure active output controls

1. Disable the signal by Exposure Active Output Line Mode for the selected output line.
2. Select the desired line for exposure active output signal by Exposure Active Output Line.
3. Set the selected line to output (option: enable *Invert* to invert exposure active output signal) by Line Configuration.
3. Enable the exposure active output signal by Exposure Active Output Line Mode.
4. Read the signal level from the oscilloscope (option: use Line Status).

## 0x00C8 | Exposure Active Output Line Mode

Enables or disables the exposure active output signal on the line selected by Exposure Active Output Line.

<b>Offset</b>	0x00C8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

Value	Description
0	<b>Off:</b> The signal is disabled.
1	<b>On:</b> The signal is enabled.

## 0x00CC | Exposure Active Output Line

Selects the physical output line for the exposure active output signal.

**Note:** Exposure Active Output Line Mode must be set to *Off* before output lines can be changed.

<b>Offset</b>	0x00CC
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
<i>0</i>	Line2 is selected.
<i>1</i>	Line3 is selected.



## 0x00D0 | Line Configuration

Configures the line as input or output and inverted or not-inverted.

**Note:** To get **constant low** on a line, please set the line to output mode with invert bit set to 0. For **constant high**, please set the invert bit to 1.

<b>Offset</b>	0x00D0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Availability</b>	All camera models

Bit offset (lsb << X)	Width (bits)	Description
0	1	Line2 is set to input or output.
1	1	Line2 is set to inverted or not inverted.
2 to 7	6	Reserved
8	1	Line3 is set to input or output.
9	1	Line3 is set to inverted or not inverted.
10 to 31	22	Reserved

To switch between input or output, set bits as follows:

Value	Description
0	<b>False:</b> The selected line is set to input.
1	<b>True:</b> The selected line is set to output.

To switch between inverted and not inverted, set bits as follows:

Value	Description
0	<b>False:</b> The selected line is set to not inverted.
1	<b>True:</b> The selected line is set to inverted.

## 0x00D4 | Line Status

Returns the logical state (high or low) of the selected line.

<b>Offset</b>	0x00D4
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Bit offset (lsb &lt;&lt; X)</b>	<b>Width (bits)</b>	<b>Description</b>
0	1	The logical state (high or low) of Line2 is returned
1	1	The logical state (high or low) of Line3 is returned

The logical state of the selected line is displayed as follows:

<b>Value</b>	<b>Description</b>
0	<b>False:</b> The logical state is low.
1	<b>True:</b> The logical state is high.

# Image Format Control

## 0x0100 | Width

Controls the current image width.

<b>Offset</b>	0x0100
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0104 | Width Min Value

Displays the minimum image width available.

<b>Offset</b>	0x0104
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0108 | Width Max Value

Displays the maximum image width available.

<b>Offset</b>	0x0108
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x010C | Width Increment

Displays the increment value available for **Width**.

<b>Offset</b>	0x010C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0110 | Height

Controls the current image height.

<b>Offset</b>	0x0110
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0114 | Height Min Value

Displays the minimum image height available.

<b>Offset</b>	0x0114
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0118 | Height Max Value

Displays the maximum image height available.

**Note:** This excludes region of interest, as known from GenICam SFNC features.

<b>Offset</b>	0x0118
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x011C | Height Increment

Displays the increment value available for **Height**.

<b>Offset</b>	0x011C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0120 | Offset X

Controls the horizontal offset from the origin to the region of interest (ROI).

<b>Offset</b>	0x0120
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0124 | Offset X Min Value

Displays the minimum value available for **Offset X**.

<b>Offset</b>	0x0124
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0128 | Offset X Max Value

Displays the maximum value available for **Offset X**.

<b>Offset</b>	0x0128
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x012C | Offset X Increment

Displays the increment value available for **Offset X**.

<b>Offset</b>	0x012C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0130 | Offset Y

Controls the vertical offset from the origin to the region of interest (ROI).

<b>Offset</b>	0x0130
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0134 | Offset Y Min Value

Displays the minimum value available for **Offset Y**.

<b>Offset</b>	0x0134
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0138 | Offset Y Max Value

Displays the maximum value available for **Offset Y**.

<b>Offset</b>	0x0138
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x013C | Offset Y Increment

Displays the increment value available for **Offset Y**.

<b>Offset</b>	0x013C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0140 | MIPI Data Format

Controls the (pixel) data format provided by the camera.

<b>Offset</b>	0x0140
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Availability</b>	Sensor model dependent

<b>Name</b>	<b>Value</b>	<b>Description</b>
<i>YUV422 8-bit (UYVY)</i>	0x1E	Selects YUV422 8-bit (UYVY).
<i>RGB888 (RGB3)</i>	0x24	Selects RGB888 (RGB3).
<i>RAW8 (GREY)</i>	0x2A	Selects RAW8 (GREY) data.
<i>RAW10 (Y10)</i>	0x2B	Selects RAW10 (Y10) data.
<i>RAW12 (Y12)</i>	0x2C	Selects RAW12 (Y12) data.



### Pixel format availability and naming

- The **availability** of pixel formats depends on camera models and the abilities of the connected system.
- For the **naming**, see [Pixel format naming](#) on page 16.



## 0x0148 | Available MIPI Data Formats

Displays a bitmap with the representation of the available MIPI (pixel) data formats.

<b>Offset</b>	0x0148
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	Sensor model dependent

Bit offset (LSB << x)	Width (bits)	Description
0 to 4	5	Reserved
5	1	YUV422 8-bit (UYVY) is available.
6	1	Reserved.
7	1	RGB888 (RGB3) is available.
8 to 13	6	Reserved
14	1	RAW8 (GREY) is available.
15	1	RAW10 (Y10) is available.
16	1	RAW12 (Y12) is available.
17 to 63	47	Reserved <b>Set to 0.</b>



### Pixel format availability and naming

- The **availability** of pixel formats depends on camera models and the abilities of the connected system.
- For the **naming**, see [Pixel format naming](#) on page 16.

## 0x0150 | Bayer Pattern Inquiry

Displays the Bayer pattern availability for RAW formats, independent of the currently selected MIPI Data Format.

<b>Offset</b>	0x0150
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	1	Monochrome format is available.
1	1	Bayer GR is available.
2	1	Bayer RG is available.
3	1	Bayer GB is available.
4	1	Bayer BG is available.
5 to 7	3	Reserved. <b>Set to 0.</b>

## 0x0154 | Bayer Pattern

Controls the Bayer pattern for RAW formats. If the current MIPI Data Format is not a RAW format, this register value is ignored.

<b>Offset</b>	0x0154
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	1	Selects monochrome format.
1	1	Selects Bayer GR.
2	1	Selects Bayer RG.
3	1	Selects Bayer GB.
4	1	Selects Bayer BG.

## 0x0158 | Reverse X

Flips the image horizontally.

**Note:** Cropping is applied after this control.

See [Control interdependencies](#) on page 25.

<b>Offset</b>	0x0158
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	1	Image remains unchanged.
1	1	The image is flipped horizontally.

## 0x015C | Reverse Y

Flips the image vertically.

**Note:** Cropping is applied after this control.

See [Control interdependencies](#) on page 25.

<b>Offset</b>	0x015C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	1	Image remains unchanged.
1	1	The image is flipped vertically.

## 0x0160 | Sensor Width

Displays the number of horizontal pixels of the image sensor.

<b>Offset</b>	0x0160
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0164 | Sensor Height

Displays the number of vertical pixels of the image sensor.

<b>Offset</b>	0x0164
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0168 | Width Max

Displays the number of horizontal pixels of the image sensor available, after binning and before region of interest has been applied.

<b>Offset</b>	0x0168
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x016C | Height Max

Displays the number of vertical pixels of the image sensor available, after binning and before region of interest has been applied.

<b>Offset</b>	0x016C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	Pixel
<b>Availability</b>	All camera models

## 0x0170 | Binning Inquiry

Displays the availability of binning factors.

**Note:** This control is available with NVIDIA Driver 5.1 or higher.

<b>Offset</b>	0x0170
<b>Origin of control</b>	Camera
<b>Type</b>	UInt16
<b>Access</b>	R
<b>Size [Bytes]</b>	2
<b>Availability</b>	All camera models

Bit offset (LSB << x)	Width (bits)	Description
0	1	2 × 2 Digital
1	1	3 × 3 Digital
2	1	4 × 4 Digital
3	1	5 × 5 Digital
4	1	6 × 6 Digital
5	1	7 × 7 Digital
6	1	8 × 8 Digital
7	1	2 × 2 Sensor
8	1	4 × 4 Sensor
9 to 15	7	Reserved Set to 0.

## 0x0174 | Binning Setting

Controls the binning factor.

**Note:** This control is available with NVIDIA Driver 5.1 or higher.

<b>Offset</b>	0x0174
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
0	Off (1 × 1) (Default)
1	2 × 2 Digital
2	3 × 3 Digital
3	4 × 4 Digital
4	5 × 5 Digital
5	6 × 6 Digital
6	7 × 7 Digital
7	8 × 8 Digital
8	2 × 2 Sensor
9	4 × 4 Sensor

## 0x0178 | Binning Mode

Controls whether the result of binned pixels is averaged or summed up.

**Note:** This control is available with NVIDIA Driver 5.1 or higher.

<b>Offset</b>	0x0178
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
0	Average: The charge or gray value of adjacent pixels is averaged.
1	Sum: The charge or gray value of adjacent pixels is summed up.

# Brightness Control

## 0x0180 | Exposure Time

Sets the exposure time when **Exposure Auto** is *Off*. This controls the duration during which the photosensitive cells are exposed to light.

<b>Offset</b>	0x0180
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Unit</b>	Nanoseconds [ns]
<b>Availability</b>	All camera models

## 0x0188 | Exposure Time Min Value

Displays the minimum value available for **Exposure Time**.

<b>Offset</b>	0x0188
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Nanoseconds [ns]
<b>Availability</b>	All camera models

## 0x0190 | Exposure Time Max Value

Displays the maximum value available for **Exposure Time**.

<b>Offset</b>	0x0190
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Nanoseconds [ns]
<b>Availability</b>	All camera models



## 0x0198 | Exposure Time Increment

Displays the increment value available for **Exposure Time**.

<b>Offset</b>	0x0198
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Nanoseconds [ns]
<b>Availability</b>	All camera models

## 0x01A0 | Exposure Auto

Sets the auto exposure mode. The output of the auto exposure function affects the whole image. **Exposure Time** is disabled.

**Note:** The pixel intensity is set to a target value of 50% of the mean. Use **Intensity Auto Target** controls to adjust the target value or use **Intensity Auto Precedence** to set the priority between **Exposure Auto** and **Gain Auto**.

<b>Offset</b>	0x01A0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	Camera model dependent

<b>Value</b>	<b>Description</b>
0	<i>Off</i> : Exposure duration is user controlled using <b>Exposure Time</b> .
1	<i>Once</i> : Exposure duration is adjusted once by the device. After it has converged, it returns to the <i>Off</i> state.
2	<i>Continuous</i> : Exposure duration is constantly adjusted by the device according to scene illumination.

## 0x0330 | Exposure Auto Min Value

Controls the minimum value for auto exposure time. The range of this register is:

- Exposure Auto Min  $\geq$  Exposure Time Min
- Exposure Auto Min  $\leq$  Exposure Time Max
- Exposure Auto Min  $\leq$  Exposure Auto Max

### Notes:

- This control is not supported by CSI-2 driver versions up to V1.0.4.
- This control must be displayed as available in **Register Inquiry** and Exposure Auto Max value must not be 0.

<b>Offset</b>	0x0330
<b>Origin of control</b>	Camera
<b>Type</b>	Int64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Unit</b>	Nanoseconds [ns]
<b>Availability</b>	Camera model dependent

## 0x0338 | Exposure Auto Max Value

Controls the maximum value for auto exposure time. The range of this register is:

- Exposure Auto Max  $\geq$  Exposure Time Min
- Exposure Auto Max  $\leq$  Exposure Time Max
- Exposure Auto Max  $\geq$  Exposure Auto Min

### Notes:

- This control is not supported by CSI-2 driver versions up to V1.0.4.
- This control must be displayed as available in **Register Inquiry** and Exposure Auto Max value must not be 0.

<b>Offset</b>	0x0338
<b>Origin of control</b>	Camera
<b>Type</b>	Int64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Unit</b>	Nanoseconds [ns]
<b>Availability</b>	Camera model dependent

## 0x01A4 | Intensity Auto Precedence

Selects the priority between exposure and gain control loops for auto intensity.

**Note:** This parameter is used only if both **Exposure Auto** and **Gain Auto** are available and set to *Once* or *Continuous*.

<b>Offset</b>	0x01A4
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All camera models

<b>Value</b>	<b>Description</b>
<i>0</i>	<i>Minimize noise</i> : Loops for <b>Exposure Time</b> are applied before loops for <b>Gain</b> .
<i>1</i>	<i>Minimize blur</i> : Loops for <b>Gain</b> are applied before loops for <b>Exposure Time</b> .

## 0x01A8 | Intensity Auto Target Value

Controls the target value for pixel intensity with auto controls.

**Note:** This control has a tolerance of 5%.

<b>Offset</b>	0x01A8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	0.1%
<b>Availability</b>	All camera models

## 0x01AC | Intensity Auto Target Min Value

Displays the minimum target value available for pixel intensity with auto controls.

<b>Offset</b>	0x01AC
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	0.1%
<b>Availability</b>	All camera models

## 0x01B0 | Intensity Auto Target Max Value

Displays the maximum target value available for pixel intensity with auto controls.

<b>Offset</b>	0x01B0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	0.1%
<b>Availability</b>	All camera models

## 0x01B4 | Intensity Auto Target Increment

Displays the increment for target values available for pixel intensity with auto controls.

<b>Offset</b>	0x01B4
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	0.1%
<b>Availability</b>	All camera models

## 0x01B8 | Black Level

Controls the analog black level as DC offset applied to the video signal.

<b>Offset</b>	0x01B8
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Availability</b>	Camera model dependent

## 0x01BC | Black Level Min Value

Displays the minimum value available for **Black Level**.

<b>Offset</b>	0x01BC
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	Camera model dependent

## 0x01C0 | Black Level Max Value

Displays the maximum value available for **Black Level**.

<b>Offset</b>	0x01C0
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	Camera model dependent

## 0x01C4 | Black Level Increment

Displays the increment value available for **Black Level**.

<b>Offset</b>	0x01C4
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	Camera model dependent

## 0x01C8 | Gain

Controls the amplification factor applied to the video signal.

<b>Offset</b>	0x01C8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Unit</b>	Millibel ( $1/_{100}$ Decibel)
<b>Availability</b>	Camera model dependent

## 0x01D0 | Gain Min Value

Displays the minimum value available for **Gain**.

<b>Offset</b>	0x01D0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Millibel ( $1/_{100}$ Decibel)
<b>Availability</b>	Camera model dependent

## 0x01D8 | Gain Max Value

Displays the maximum value available for **Gain**.

<b>Offset</b>	0x01D8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Millibel ( $1/_{100}$ Decibel)
<b>Availability</b>	Camera model dependent

## 0x01E0 | Gain Increment

Displays the increment value available for **Gain**.

<b>Offset</b>	0x01E0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Unit</b>	Millibel ( $1/_{100}$ Decibel)
<b>Availability</b>	Camera model dependent

## 0x01E8 | Gain Auto

Controls the automatic gain control (AGC) mode. The output of the auto gain function affects the whole image.

**Note:** The pixel intensity is set to a target value of 50% of the mean. Use **Intensity Auto Target** controls to adjust the target value or use **Intensity Auto Precedence** to set the priority between **Exposure Auto** and **Gain Auto**.

<b>Offset</b>	0x01E8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	Camera model dependent

<b>Value</b>	<b>Description</b>
<i>0</i>	<i>Off</i> : Gain is User-controlled using <b>Gain</b> .
<i>1</i>	<i>Once</i> : Gain is adjusted once by the device. After it has converged, it returns to the <i>Off</i> state.
<i>2</i>	<i>Continuous</i> : Gain is constantly adjusted by the device according to scene illumination.

## 0x0340 | Gain Auto Min Value

Controls the minimum value for auto gain. The range of this register is:

- Gain Auto Min  $\geq$  Gain Min
- Gain Auto Min  $\leq$  Gain Max
- Gain Auto Min  $\leq$  Gain Auto Max

### Notes:

- This control is not supported by CSI-2 driver versions up to V1.0.4.
- This control must be displayed as available in Register Inquiry and Gain Auto Max value must not be 0.

<b>Offset</b>	0x0340
<b>Origin of control</b>	Camera
<b>Type</b>	Int64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Unit</b>	Millibel (1/100 Decibel)
<b>Availability</b>	All camera models

## 0x0348 | Gain Auto Max Value

Controls the maximum value for auto gain. The range of this register is:

- Gain Auto Max  $\geq$  Gain Min
- Gain Auto Max  $\leq$  Gain Max
- Gain Auto Max  $\geq$  Gain Auto Min

### Notes:

- This control is not supported by CSI-2 driver versions up to V1.0.4.
- This control must be displayed as available in Register Inquiry and Gain Auto Max value must not be 0.

<b>Offset</b>	0x0348
<b>Origin of control</b>	Camera
<b>Type</b>	Int64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Unit</b>	Millibel (1/100 Decibel)
<b>Availability</b>	All camera models



## 0x01F0 | Gamma

Controls the correction of pixel intensity.

$$Y' = (Y / Y_{\max})^{(\text{Gamma} \times 0.01)} \times Y_{\max}$$

where

Y' is the new pixel intensity

Y is the original pixel intensity

Y<sub>max</sub> is the maximum pixel value (for example, 255 for RAW8)

Gamma is the hundredfold correction factor.

<b>Offset</b>	0x01F0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Availability</b>	Camera model dependent

## 0x01F8 | Gamma Min Value

Displays the minimum value available for **Gamma**.

<b>Offset</b>	0x01F8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	Camera model dependent

## 0x0200 | Gamma Max Value

Displays the maximum value available for **Gamma**.

<b>Offset</b>	0x0200
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	Camera model dependent

## 0x0208 | Gamma Increment

Displays the increment value available for **Gamma**.

<b>Offset</b>	0x0208
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	Camera model dependent

# Color Management

## 0x0240 | Saturation

Controls the amplification of the chrominance signal as  $100 \times$  factor.

<b>Offset</b>	0x0240
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Availability</b>	All color models

## 0x0244 | Saturation Min Value

Displays the minimum value available for **Saturation**.

<b>Offset</b>	0x0244
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All color models

## 0x0248 | Saturation Max Value

Displays the maximum value available for **Saturation**.

<b>Offset</b>	0x0248
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All color models

## 0x024C | Saturation Increment

Displays the increment value available for **Saturation**.

<b>Offset</b>	0x024C
<b>Origin of control</b>	Camera
<b>Type</b>	UInt32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All color models

## 0x0250 | Hue

Controls the color tone by rotating the chrominance field clockwise with values > 0 and counter clockwise with values < 0. Values are 100 × factor.

<b>Offset</b>	0x0250
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R/W
<b>Size [Bytes]</b>	4
<b>Unit</b>	$\frac{1}{100}$ degrees [°]
<b>Availability</b>	All color models

## 0x0254 | Hue Min Value

Displays the minimum value available for **Hue**.

<b>Offset</b>	0x0254
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All color models

## 0x0258 | Hue Max Value

Displays the maximum value available for Hue.

<b>Offset</b>	0x0258
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All color models

## 0x025C | Hue Increment

Displays the increment value available for Hue.

<b>Offset</b>	0x025C
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Availability</b>	All color models

## 0x0280 | Red Balance Ratio

Controls the ratio of the red color component to the green color component (variable C). It is used for white balancing. The color balance is realized by the following formula:

$$C_w = \text{Red Balance Ratio} \times C$$

$C_w$ : Intensity of selected color component after white balancing

**Red Balance Ratio**: White balance coefficient

C: Intensity of the color component before white balancing.

<b>Offset</b>	0x0280
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x0288 | Red Balance Ratio Min Value

Displays the minimum value available for **Red Balance Ratio**.

<b>Offset</b>	0x0288
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x0290 | Red Balance Ratio Max Value

Displays the maximum value available for **Red Balance Ratio**.

<b>Offset</b>	0x0290
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x0298 | Red Balance Ratio Increment

Displays the increment value available for **Red Balance Ratio**.

<b>Offset</b>	0x0298
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x02C0 | Blue Balance Ratio

Controls the ratio of the blue color component to the green color component (variable C). It is used for white balancing. The color balance is realized by the following formula:

$$C_w = \text{Blue Balance Ratio} \times C$$

$C_w$ : Intensity of selected color component after white balancing

**Blue Balance Ratio**: White balance coefficient

C: Intensity of the color component before white balancing.

<b>Offset</b>	0x02C0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R/W
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x02C8 | Blue Balance Ratio Min Value

Displays the minimum value available for **Blue Balance Ratio**.

<b>Offset</b>	0x02C8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x02D0 | Blue Balance Ratio Max Value

Displays the maximum value available for **Blue Balance Ratio**.

<b>Offset</b>	0x02D0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x02D8 | Blue Balance Ratio Increment

Displays the increment value available for **Blue Balance Ratio**.

<b>Offset</b>	0x02D8
<b>Origin of control</b>	Camera
<b>Type</b>	UInt64
<b>Access</b>	R
<b>Size [Bytes]</b>	8
<b>Availability</b>	All color models

## 0x02E0 | White Balance Auto

Controls the mode for automatic white balancing between the color channels. The white balancing ratios are adjusted automatically.

<b>Offset</b>	0x02E0
<b>Origin of control</b>	Camera
<b>Type</b>	UInt8
<b>Access</b>	R/W
<b>Size [Bytes]</b>	1
<b>Availability</b>	All color models

<b>Value</b>	<b>Description</b>
<i>0</i>	<i>Off</i> : The automatic adjustment of white balance is turned off.
<i>1</i>	<i>Once</i> : White balance is adjusted once by the device. Once it has converged, it returns to the <i>Off</i> state.
<i>2</i>	<i>Continuous</i> : White balance is constantly adjusted by the device.



## Other

### 0x0310 | Device Temperature

Displays the temperature of the camera.

<b>Offset</b>	0x0310
<b>Origin of control</b>	Camera
<b>Type</b>	Int32
<b>Access</b>	R
<b>Size [Bytes]</b>	4
<b>Unit</b>	$\frac{1}{10} \text{ } ^\circ\text{C} = \text{d}^\circ\text{C}$
<b>Availability</b>	Camera model dependent

# Index

## A

Acquisition Control (controls category) .....	34
Acquisition Frame Rate .....	36
Acquisition Frame Rate Enable .....	37
Acquisition Frame Rate Max Value .....	36
Acquisition Frame Rate Min Value .....	36
Acquisition Start .....	34
Acquisition Status .....	35
Acquisition Stop .....	35
Allied Vision contact .....	3
Available MIPI Data Formats .....	49

## B

Bayer Pattern .....	50
Bayer Pattern Inquiry .....	50
Black Level .....	61
Black Level Increment .....	61
Black Level Max Value .....	61
Black Level Min Value .....	61
Blue Balance Ratio .....	71
Blue Balance Ratio Increment .....	72
Blue Balance Ratio Max Value .....	71
Blue Balance Ratio Min Value .....	71
Brightness Control (controls category) .....	56
Buffer Size .....	33

## C

Camera I2C Address .....	21
CCI Register Layout Version .....	17, 18
Checksum .....	20
Color Management (controls category) .....	67
CSI-2 Clock .....	32
CSI-2 Clock Max Value .....	32
CSI-2 Clock Min Value .....	32
CSI-2 Lane Count .....	31
CSI-2 Phy Reset .....	33

## D

Device Capabilities .....	18
Device Firmware Version .....	29
Device GUID .....	18

Device Temperature .....	73
Device Version .....	19
Digital Binning Inquiry .....	53
Digital Binning Setting .....	54, 55

## E

Exposure Active Output Line .....	40
Exposure Active Output Line Mode .....	39
Exposure Auto .....	57
Exposure Auto Max Value .....	58
Exposure Auto Min Value .....	58
Exposure Time .....	56
Exposure Time Increment .....	57
Exposure Time Max Value .....	56
Exposure Time Min Value .....	56

## F

Family Name .....	19
Frame Start Trigger Activation .....	38
Frame Start Trigger Mode .....	37
Frame Start Trigger Software .....	39
Frame Start Trigger Source .....	38

## G

Gain .....	62
Gain Auto .....	63
Gain Auto Max Value .....	64
Gain Auto Min Value .....	64
Gain Increment .....	63
Gain Max Value .....	62
Gain Min Value .....	62
Gamma .....	65
Gamma Increment .....	66
Gamma Max Value .....	65
Gamma Min Value .....	65
General (controls category) .....	27

## H

Heartbeat .....	21
Height .....	44
Height Increment .....	45
Height Max .....	53
Height Max Value .....	45
Height Min Value .....	44
Hue .....	68
Hue Increment .....	69

Hue Max Value.....	69
Hue Min Value .....	68

## I

Image Format Control (controls category) .....	43
Intensity Auto Precedence .....	59
Intensity Auto Target Increment.....	60
Intensity Auto Target Max Value.....	60
Intensity Auto Target Min Value .....	60
Intensity Auto Target Value.....	59

## L

Line Configuration .....	41
Line Status .....	42

## M

Manufacturer Info .....	19
Manufacturer Name.....	19
MIPI Data Format .....	48
Model Name .....	19

## O

Offset X .....	45
Offset X Increment .....	46
Offset X Max Value .....	46
Offset X Min Value.....	46
Offset Y .....	47
Offset Y Increment.....	48
Offset Y Max Value .....	47
Offset Y Min Value .....	47
Other (controls category).....	73

## R

Red Balance Ratio.....	69
Red Balance Ratio Increment .....	70
Red Balance Ratio Max Value.....	70
Red Balance Ratio Min Value .....	70
Register Inquiry.....	28
Reverse X .....	51
Reverse Y .....	51
R, access mode .....	13
R/C, access mode.....	13
R/W, access mode .....	13

## S

Saturation.....	67
Saturation Increment.....	68
Saturation Max Value .....	67
Saturation Min Value .....	67
Selectors.....	13
Sensor Height.....	52
Sensor Width.....	52
Serial Number .....	20
Soft Reset .....	21
Streaming Control (controls category).....	31
support.....	3
Supported CSI-2 Lane Counts .....	31

## U

User Defined Name.....	20
------------------------	----

## V

V4L2 Register Map Address.....	18
V4L2 Register Map Version.....	27

## W

White Balance Auto .....	72
Width.....	43
Width Increment.....	44
Width Max.....	52
Width Max Value .....	43
Width Min Value .....	43
Write Done Handshake.....	30
W, access mode .....	13