





Alvium FP3-501 NIR Coax

- AR0522 CMOS sensor
- 5.0 MP resolution
- ALVIUM image processing
- FPD-Link III interface
- Mono and color models

Model without hardware options

### Robust CSI-2 based Alvium cameras with FPD-Link III interface

Benefit from greater flexibility in cable lengths

Alvium FP3 Coax cameras with FPD-Link III (Flat Panel Display Link) interface have been designed to overcome the limitations of standard CSI-2 cameras. The closed housing CSI-2 based cameras come with integrated serializer and a rugged coaxial-based FAKRA connector for thin coax cables. With Alvium FP3 Coax, cable lengths up to 15 meters are possible. The coax cable can also be used to power the camera (Power over coax) enabling a single cable solution.

The standardized CSI-2 driver ensures quick integration with the flexibility to change camera models easily.

To operate Alvium FP3 cameras on your vision system, Allied Vision provides different access modes: - Direct Register Access (DRA) to control the cameras via registers for advanced users. -Video4Linux2 Access allows to control the cameras via established V4L2 API and applications like GStreamer and OpenCV. Open-source CSI-2 drivers are available on GitHub for different boards and systems on chip (SoCs).

In addition to lens mount and housing options, see Customization and OEM Solutions webpage for additional options.



# Specifications

Interface	FPD-Link III, based on MIPI CSI-2, up to 4 lanes
Resolution	2592 (H) × 1944 (V)
Spectral range	300 to 1100 nm
Sensor	ON Semi AR0522
Sensor type	CMOS
Shutter mode	RS (Rolling shutter)
Sensor size	Type 1/2.5
Pixel size	2.2 μm × 2.2 μm
Lens mounts (available)	C-Mount, CS-Mount, S-Mount 68
Max. frame rate at full resolution	Mainly depends on hardware and register settings.
ADC	10 Bit
Image buffer (RAM)	256 KByte
Non-volatile memory (Flash)	1024 KByte


Output	
Bit depth	10-bit
YUV color pixel formats	YUV422 8-bit (UYVY) [MIPI CSI-2 (FOURCC)]
RGB color pixel formats	RBG888 (RGB3) [MIPI CSI-2 (FOURCC)]
Raw pixel formats	RAW8 (GREY), RAW10 (Y10) [MIPI CSI-2 (FOURCC)]

General purpose inputs/outputs (GPIOs)		
TTL I/Os	2 programmable GPIOs	

Operating conditions/dimensions	
Operating temperature	-20 °C to +65 °C (housing)
Power requirements (DC)	5 VDC over MIPI CSI-2
Power consumption	Value for the integrated serializer adds to CSI-2 model value.
Mass	70 g
Body dimensions (L $\times$ W $\times$ H in mm)	41 x 29 x 29



Quantum efficiency





### Features

#### Image control: Auto

- Auto exposure
- Auto gain
- Auto white balance (color models)

#### Image control: Other


- Black level
- Color transformation (incl. hue, saturation; color models)
- De-Bayering up to 5×5 (color models)
- DPC (defect pixel correction)
- FPNC (fixed pattern noise correction)
- Gamma
- Reverse X/Y
- ROI (region of interest)

#### Camera control


- Acquisition frame rate
- Firmware update in the field
- I/O and trigger control
- Temperature monitoring





# Technical drawing











13 ±0.1

20 ±0.1

M3 - 2.2 ∓ (2x)

 $\odot$ 

Q

