



PCN Title Alvium GMSL2 Hardware Change to Support Pixel Mode

Affected Products Alvium GM2 Coax, GM2 STP cameras and GMSL2 Deserializer Boards

PCN Number PCN2024-04-24 **PCN Issue date** 23.04.2024

Contact <u>Inside Sales Team</u>

Change Classification

Minor

Change Type

Electronical Specification

Affected Products

See Annex

Change Description

Hardware Change for all Alvium GM2 Coax and Alvium GM2 STP camera models and GMSL2 deserializer boards

Reason for Change

First series Alvium GM2 cameras and deserializer boards for GMSL2 used the Reference over Reverse (RoR) feature and the tunneling mode. Because typical available carrier boards do not support RoR and use pixel mode, camera and deserializer hardware have been changed. See Alvium FP3/GM2 User Guide and user guides for GMSL2 deserializer boards for details.

Impact / Possible Successor

There is no impact on existing setups: the Alvium GM2 cameras are backwards compatible.

As a major advantage more deserializers are supported now.

First Ship Date

2024-05-06

The information provided in this product change notification are subject to change without notice. For the latest version of this document, please visit the Allied Vision <u>website</u>.

Support: General inquiries:

In case of technical questions please contact our <u>Support Team</u> Please contact our <u>Inside Sales Team</u>



Annex

Item no. affected products

19482
20413
19291
19293
19343
19348
19519
19564
19565
20644
19359
19373
20829
19355
19356
20910
20959
21091
21211
21326
21445
21467
21526
21539
21541
21557